

Type S Mortar

A LaFarge experiment:

LAB	FIELD
-----	-------

	<u>C270</u> 2" cubes made in the LAB	<u>C780</u> <i>Kinda</i> 2 x 2 Field Cubes	<u>ACI 531.1</u> 2" dia. cylinder after spread on block	<u>ASTM</u> <u>C-1019</u> 4" x 4" Prism
7 Day	1987	1350	1760	1740
28 Day	2510	1660	2090	1925

* Spread mortar on the block for one minute at about 1/2" to 3/4" thickness then put into 2" dia. cylinder

*

28 Day Strength Chart

